

CHANGE EFFICIENCY AS FOLLOWS	NUMBER OF POINTS	FOR NUMBER OF STAGES

NOTE: ANY CHANGE IN EFFICIENCY
CHANGES EITHER THE HEAD OR
HORSE POWER IN PROPORTION.



6 PF

1750 R P M

SINGLE STAGE LABORATORY
HEAD & HORSE POWER
THRUST "K" = 6.1

